

## Plastic pit with riser for increased depth Relevant to pit Type 1-8 & 53

### - STEP BY STEP INSTALLATION INSTRUCTIONS

The following instructions detail how to modify a typical plastic pit to increase the pit height with a riser. 2 pits are required.

1. Cut one pit below the step at the cutting line. Use an angle grinder with a cutting disc or cut with a hand saw. The top section will be used as the riser, discard the bottom section. Smooth cut edges with a rough file.



2. Place the riser into the rebate area of the second pit.



Bulletin No.: TB201304  
Date: 3 April 2013  
Issued By: CC